

ANDERLYN DESK SET UP INSTRUCTIONS



STEP ONE:

Take “Anderlyn Desk” out of box, remove protective covering, place the flat desk top *face down* on sturdy desk or table with handle cut-out facing you.



STEP FOUR:

Remove stabilizing bar.



STEP TWO:

Adjust side legs (while flat) by removing screws with a Phillips Screwdriver and slide adjustable panel to desired height position. Secure screws.



STEP FIVE:

Lift side legs to meet middle leg. Align pins with holes and insert pins.



No adjustment necessary for 4'11" to 5'5"
Slide panels to first set of holes for 5'5" to 5'11"
Slide panels to second set of holes for 6' to 6'6"

WARNING

DO NOT STAND or **SIT** on desk.

DO NOT EXCEED 25lbs on top of desk.

Recommended for a Flat Screen Monitor or a Lap Top Computer.



STEP THREE:

Lift middle section leg (with logo) towards you into upright position.
(If height adjustment is necessary, remove screws, slide panel to desired position and secure screws.)
Hold in place.



STEP SIX:

Turn “Anderlyn Stand-Up Desk” over onto your existing desk with opening toward you and align pins on stabilizing bar with holes on legs. Insert pins.



Ready For Use